

POST TREATMENT
1400534_004_004
QUARTERLY
BACTERIOLOGICAL (COLIFORM)
(MAR, JUN, SEPT, DEC)

Fill chain of custody form.

Take small clear sample bottle and fill out info. (Bottle does not have label. Wetlab said can mark bottle with sharpie marker.)

Info must include:

Tecopa water vending machine

DATE When sample was taken.

CODE 1400534_004_004

YOUR NAME

This will be last sample taken from vending machine. By now TDS/Fluoride (same bottle), Arsenic samples should have already been taken.

Wash hands again before taking sample. (Only cold side of sink works).

Go out to vending machine and insert 1 quarter and start dispensing water to fill bottle. Be careful not to touch inside of cap.

Replace cap.

All bottle samples taken from vending machine must all have the same time written on c of c form.

Put all bottles in a cooler to take to Shoshone store. Coliform samples must be delivered to WETlab within 24 hours.

Take sample to Shoshone store. Sign, date, and time relinquished to store clerk. Let clerk know to refrigerate sample. Leave c of c form with clerk. Susan Sorrells will take samples to Vegas the next day.

Call or text Susan to let her know you dropped off the water sample.